



by STOPARTS LTD



Rock Drill Machinery & Drifters spare parts



2020 - 2021

INTERACTIVE INDEX

ATLAS COPCO

- 4 Drifter
- 9 DTH Drill Machine
- 13 Rock Drill Machine

EVERDIGM

- 19 Drifter

INGERSOLL RAND

- 22 Drifter
- 26 Rock Drill Machine

JUNJIN

- 31 Drifter

MINE MASTER

- 34 Drifter

SOOSAN

- 37 Drifter

Driver

3115158200

3115 1582 00



Needle bearing

0516150401

0516 1504 01



Valve

3115026200

3115 0262 00



Dome nut

3115028600

3115 0286 00



Coupling

3115027700

3115 0277 00



Sleeve

3115082400

3115 0824 00



Roller bearing

0509022100


0509 0221 00



Gear

3115027400

3115 0274 00



Shaft

3115082100

3115 0821 00



Valve cover right

3115141800

3115 1418 00



Side Bolt

3115145700

3115 1457 00



Cover

3115136400

3115 1364 00



Guide

3115211900

3115 2119 00



Stop ring

3115211780

3115 2117 80



Connection plate

3115193800

3115 1938 00



Valve piston

3115176500

3115 1765 00



Diaphragm

3115182200

3115 1822 00



Valve cover right

3115207605

3115 2076 05



Diaphragm

3115192602

3115 1926 02



Rotation chuck

3115173281

3115 1732 81



Bushing

3115188100

3115 1881 00



Bushing

3115208400

3115 2084 00



Piston guide rear

3115168000

3115 1680 00



Piston guide front

3115167100

3115 1671 00



Side bolt

3115265100

3115 2651 00



Flushing head

3115212100

3115 2121 00



Piston

3115212600

3115 2126 00



Return accumulator

3115261590

3115 2615 90



Rotation chuck

3115264980

3115 2649 80



Rotation bushing

3115220000

3115 2200 00



Piston damping

3115238200

3115 2382 00



Diaphragm

3115247200

3115 2472 00



Driver

3115265000

3115 2650 00



Test valve complete

3115219681

3115 2196 81



Piston guide

3115212400

3115 2124 00



Stop ring

3115212200

3115 2122 00



Side bolt

3115265200

3115 2652 00



Regulating plug

3115329100

3115 3291 00



Liner

3115347400

3115 3474 00



Front head

3115295000

3115 2950 00



Damping piston

3115297100

3115 2971 00



Rotation chuck bushing

3115296800

3115 2968 00



Accumulator

3115345181

3115 3451 81



Housing accumulator

3115269700

3115 2697 00



Accumulator intake

3115290080

3115 2900 80



Hydraulic motor

3115347381

3115 3473 81



Seal housing

3115276080

3115 2760 80



Hydraulic motor

3115347385

3115 3473 85



Piston

3115363500

3115 3635 00



Valve cover right

3115211502

3115 2115 02



Driver

3115554300

3115 5543 00



Flushing head

3115504400

3115 5044 00



Guide

3115504501

3115 5045 01



Driver

3115554100

3115 5541 00



Piston guide

3115505001

3115 5050 01



Front head

3115504200

3115 5042 00



Piston damping

3222128850

3222 1288 50



Bushing

3115374400

3115 3744 00



Sprocket wheel

3214253600

3214 2536 00



Holder

3128078549


3128 0785 49



Jaw-2

3128082907

3128 0829 07



Flushing sleeve

3161109600


3161 1096 00



Flushing sleeve

3161102800

3161 1028 00



Slide piece

3128307488

3128 3074 88



Holder set

3128306164

3128 3061 64



Holder set

3128306181

3128 3061 81



Piston rod end

3128300268

3128 3002 68



Expanding shaft

3128302956


3128 3029 56



Jaw

3128082907

3128 0829 07



Holder

3128078439

3128 0784 39



Ring right hand

3216582700

3216 5827 00



Stop

3222323541

3222 3235 41



Shaft

3222064100


3222 0641 00



Check half carbide

3222313790

3222 3137 90



Star wheel

3222310363

3222 3103 63



Sliding piece thick

3222315344

3222 3153 44



Plate

3222319533

3222 3195 33



Shaft

3222311719

3222 3117 19



Star wheel

3222310362

3222 3103 62



Piston rod

3222311362


3222 3113 62



Spacer

3222311362

3222 3113 62



Jaw

3222063700

3222 0637 00



Rubber

3222333903

3222 3339 03



Housing

4350265006

4350 2650 06



Piston rod

3222331140

3222 3311 40



Holder set

3222 3273 63

3222 3273 63



Holder

3222328240

3222 3282 40



Intermediate shaft

4350258070

4350 2580 70



Support

3222330090

3222 3300 90



Return rope

3222332476

3222 3324 76



Bushing half

3222324781

3222 3247 81



Sealing bush

4350261900

4350 2619 00



Rope

3222323656

3222 3236 56



Bushing half

3222324780

3222 3247 80



DHR 6W

9236201240

9236 2012 40



DHR 6HU

4350276212

4350 2762 12



DHR 6H

4350276102

4350 2761 02



DHR 6RC

4350266302

4350 2663 02



Adapter

4350265041

4350 2650 41



Adapter

4350265008

4350 2650 08



Lubricating

0544216200

0544 2162 00



Seloid valve

1089045101

1089 0451 01



Level meter

1616510800

1616 5108 00



Cradle plate

3128048400

3128 0484 00



Hose drum

3128077000

3128 0770 00



Pull rope

3128078411

3128 0784 11



Profile

3128078418

3128 0784 18



Pulley wheel

3128078430

3128 0784 30



Pulley wheel

3128078534

3128 0785 34



Holder

3128078548

3128 0785 48



Holder

3128078549

3128 0785 49



Bushing hub

3128240300


3128 2403 00



Bushing half

3128240700

3128 2407 00



Half bushing

3128240702

3128 2407 02



Half bushing

3128240703

3128 2407 03



Sliding piece

3128303930

3128 3039 30



Sliding piece

3128304355

3128 3043 55



Holder

3128306163

3128 3061 63



Holder

3128306164

3128 3061 64



Holder

3128306180

3128 3061 80



Holder

3128306181

3128 3061 81



Sliding piece

3128307488

3128 3074 88



Arm

3128309733

3128 3097 33



Relay

3176000038

3176 0000 38



Hydraulic motor

3177307200

3177 3072 00



Filter cartridge

3214623900

3214 6239 00



Packing

3216933914

3216 9339 14



Push button

3217001238

3217 0012 38



Rubber hood

3217052800

3217 0528 00



Lubrication pump

3217866752

3217 8667 52



Pilot valve

3217920302

3217 9203 02



Breather filter

3222 1180 00

3222 1180 00



Sensor

3222148800

3222 1488 00



Air filter

3222188131

3222 1881 31



Air valve

3222 2124 15

3222 2124 15



Toggle switch

3222 2788 00

3222 2788 00



Toggle swicht

3222 2788 04

3222 2788 04



Swing arm

3222 3029 77

3222 3029 77



Diaphragm

3222306198

3222 3061 98



Relief valve

3222306266

3222 3062 66



Coupling

3222307624

3222 3076 24



Coupling

3222307839

3222 3078 39



Half bushing

3222309744

3222309744



Half bushing

3222309745

3222 3097 45



Handle

3222310029

3222 3100 29



Wiper

3222310031

3222310031



Coupling hup

3222314097

3222 3140 97



Air filter

3222314125


3222 3141 25



Return valve

3222317845

3222 3178 45



Air breather

3222318729

3222 3187 29



Arm

3222318911

3222 3189 11



Guide rail

3222318912

3222 3189 12



Fan wheel

3222319183

3222 3191 83



Sensor

3222322987

3222 3229 87



Coupling

3222324419

3222 3244 19



Filter

3222 3246 42

3222 3246 42



Fan

3222324896

3222 3248 96



Filter

3222 3253 76

3222 3253 76



Filter

3222 3253 78

3222 3253 78



PLC

3222327640

3222 3276 40



Water tank

3222986131

3222 9861 31



Filter

3222986146

3222986146



Air filter

5112305741

5112 3057 41



Air filter

5112306566

5112 3065 66



Air filter

5112305740

5112 3057 40



Selonoid valve

8204049897

8204 0498 97



Return filter

8231101804

8231 1018 04



Temperature sensor

9106185602

9106 1856 02



Drive wheel

9106221269

9106 2212 69



Chuck drive

D-45087200



Liner

D-45087100



Chuck end

D-45086800



Splined shank

D-45086900



Blow tube

D-40186600



Shank bushing

D-45086600



Chuck drive bushing

D-45087000



Flange

D-42049800



Pin

D-44035700



Cap

D-45086700



Bushing

D-45086600



Seal kit

D-5503000



Socket bolt

D-A011-0013



Diaphragm

D-59001003



Diaphragm

D-59001103



Screw

D-91110510



Cap bolt

D-45088300



Cover bushing

D-45088100



Drive gear

D-45087300



Cover nut

D-45088000



Side rod

D-45087900



Thrust plate

D-45087500



Orbit motor

D-52001000



Cover

D-45087800




Valve assembly
D-D1009802



Bearing
D-D1121055



Bush
D-D1005001



Piston
D-D45087600



Cylinder
D-D45087700



Plug
D-IOA03500




Socket bolt
S2219361



Accumulator
D-D129902



Accumulator
D-D1209903



Heli coil
D-A016-001D001



Guide valve

2651206316

2651 2063 16



Blow tube

2651206159

2651 2061 59



Piston

2651206332

2651 2063 32



Front liner

2651206357

2651 2063 57



Valve

2651206324

2651 2063 24



Valve

2651176741

2651 1767 41



Gland backhead

2651206134

2651 2061 34



Cap

2650748334

2650 7483 34



Bolt

2650945385

2650 9453 85



Bearing ball

2650781962

2650 7819 62



Lubricator

2651109957

2651 1099 57



Accumulator assembly

2651155125

2651 1551 25



Cylinder

2651264711

2651 2647 11



Driver chuck

2651206662

2651 2066 62



Gear idler

2651206548

2651 2065 48



Cylinder Button

2651264679

2651 2646 79



Liner cup

2651206753

2651 2067 53



Cover

2651206621

2651 2066 21



Shaft gear

2651206597

2651 2065 97



Bushing

2651206498

2651 2064 98



Diaphragm

2651206407

2651 2064 07



Needle bearing

2651206555

2651 2065 55



Gear driver

2651206522

2651 2065 22



Cover

2651206399

2651 2063 99



Seal ring kit

2653217675

2653 2176 75



Bushing set

2651533107

2651 5331 07



Bolt

2651525939

2651 5259 39



Bolt

2651324861

2651 3248 61



Nut

2651325728

2651 3257 28



Piston

2651264745

2651 2647 45



Liner

2651348183

2651 3481 83



Back liner

2651669976

2651 6699 76



Guide valve

2651317360

2651 3173 60



Chuck

2651533073

2651 5330 73



Bolt

2651275154

2651 2751 54



Chuck end

2651206746

2651 2067 46



Diaphragm

2651264828

2651 2648 28



Piston

2651317386

2651 3173 86



Hydraulic motor

2651317444


2651 3174 44



Back liner

2651669984

2651 6699 84



Valve

2651669992

2651 6699 92



Liner cap

2651964153

2651 9641 53



Unloading diaphragm

2635317197

2635 3171 97



Seperator filter

2635858927

2635 8589 27



Mufler

2636766731

2636 7667 31



Valve

2636783439

2636 7834 39



Clamp

2651101392

2651 1013 92



Liner

2651102143

2651 1021 43



Element primary

2651103240

2651 1032 40



Element safety

2651103257

2651 1032 57



Lubricator

2651109957

2651 1099 57



Nozzle spray

2651125375


2651 1253 75



Skirt

2651155869

2651 1558 69



Element safty

2651272037

2651 2720 37



Element primary

2651272060

2651 2720 60



Liner

2651287688

2651 2876 88



Plate

2651287704

2651 2877 04



Inner Liner

2651287712

2651 2877 12



Cam follower

2651287803

2651 2878 03



Stopper rod

2651314185

2651 3141 85



Filter cartridge

2651322881

2651 3228 81



Upper liner

2651339190

2651 3391 90



Lower liner

2651339208

2651 3392 08



Plate

2651339216

2651 3392 16



Roller hose

2651348324

2651 3483 24



Roller hose

2651348332


2651 3483 32



Wheel

2651522506

2651 5225 06



Valve

2651522720

2651 5227 20



Valve

2651 5227 21

2651 5227 21



Upper liner

2651525186

2651 5251 86



Lower liner

2651525194

2651 5251 94



Plate

2651525202


2651 5252 02



Air valve

2651677615

2651 6776 15



Air valve

2651677623

2651 6776 23



Relay

2651687481

2651 6874 81



Pilot valve

2652130044

2652 1300 44



Element rubber

2652299195

2652 2991 95



Hub coupling

2653085635

2653 0856 35



Relay

2653087953

2653 0879 53



Relief valve

2653090494

2653 0904 94



Gauge

2653096293

2653 0962 93



Joystick

2653128898

2653 1288 98



Cylinder air

2653142220

2653 1422 20



Half bushing

2653158093

2653 1580 93



Link

2653158341

2653 1583 41



Link

2653184420

2653 1844 20



Cylinder

2653188900

2653 1889 00



Element inner

2653207387

2653 2073 87



Element outer

2653207395

2653 2073 95



Element inner

2653207460

2653 2074 60



Element Outer

2653207478

2653 2074 78



Motor wiper

2653223012

2653 2230 12



Belt

2653231437

2653 2314 37



Wire rope

2653236386

2653 2363 86



Roller hose

2653245445

2653 2454 45



Roller hose

2653245452

2653 2454 52



Air filter

2653252359

2653 2523 59



Filter inlet

2653252367

2653 2523 67



Unloder

2654436845

2654 4368 45



Air filter

5112305740

5112 3057 40



Air filter

5112305741

5112 3057 41



Air filter

5112306566

5112 3065 66



Bearing bush

AJD7300300000

AJD7-3003000-00



Stop ring

D7J3301000002

D7J3-3010000-02



Driver

AJD9300500003

AJD9-3005000-03



Front bush

AJD9100500000

AJD9-1005000-00



Rear bush

AJD9100700000

AJD9-1007000-00



Driver

AJD8300500003

AJD8-3005000-03



Driver

AJD7300500003

AJD7-3005000-03



Chuck Gear

D7J3300400001

D7J3-3004000-01



Bearing bush

D7J3300700000

D7J3-3007000-00



Bearing bush

D7J3300200001

D7J3-3002000-01



Wear bush

D7J3400200000

D7J3-4002000-00



Flushing head

D7J3400300001

D7J3-4003000-01



Socket bolt

41010050012150

4101005-0012150



Adjuster

07J3101100000

07J3-1011000-00



Front retainer

07J3100600000

07J3-1006000-00



Stop ring

AJD7100400001

AJD7-1004000-01



Pusher

09J3301400001

09J3-3014000-01



Valve sleeve

07J3100200001

07J3-1002000-01



Hydraulic motor

3110000000160S

3110000-000160S



Damper piston

AJD7100100005

AJD7-1001000-05



Needle bearing

4011000-3004530

4011000-3004530



Socket plug

55015001060034

5501500-1060034



Cap nut

09J3400500000

09J3-4005000-00



Valve

07J3100300000

07J3-1003000-00



Tie bolt

D9J3301500001

D9J3-3015000-01



Piston

D9J3100400003

D9J3-1004000-03



Through bolt

D9J3400400000

D9J3-4004000-00



Valve

D9J3-100300005

D9J3-1003000-05



Damper

D9J3200200001

D9J3-2002000-01



Pusher

D9J3-3000100-00

D9J3-3000100-00



Pinion

D9J3301200001

D9J3-3012000-01



Valve cap

D9J3100800000

D9J3-1008000-00



Accumulator housing

D9J3500100000

D9J3-5001000-00



Stop ring

D9J3301000001

D9J3-3010000-01



Cap nut

D9J3301600001

D9J3-3016000-01



Retainer

86352416

2686 3524 16



Flushing nozzle

86645959

2686 6459 59



Hydraulic piston

86611639

2686 6116 39



Strike piston

86578580

2686 5785 80



Gear drive

86501764

2686 5017 64



Rear ring

86611621


2686 6116 21



Guding ring

86511490

2686 5114 90



Front lining

86611647

2686 6116 47



Splined shank

86511458

2686 5114 58



Slider

86653581

2686 6535 81



Shank retainer

86645967

2686 6459 67



Accumulator

86374055

2686 3740 55



Shaft

86313087

2686 3130 87



Bolt

86223716

2686 2237 16



Valve

86265048

2686 2650 48



Cover

86223914

2686 2239 14



Thrust piston

86333275

2686 3332 75



Trust piston

86333713

2686 3337 13



Gear

86313129

2686 3131 29



Cover

86324738

2686 3247 38



Cylinder

86323672

2686 3236 72



Slider

86223906

2686 2239 06



Shank stop

86223492

2686 2234 92



Holicoil thread

86264678

2686 2646 78



Spacer

86220878

2686 2208 78



Lining

86220233

2686 2202 33



Bearing

86220811

2686 2208 11



Needle bearing

86221595

2686 2215 95



Shaft

86220209

2686 2202 09



Push Rod

86220951

2686 2209 51



Ring

86221561

2686 2215 61



Ring

86221132

2686 2211 32



Liner

86220969

2686 2209 69



Needle bearing

86223021

2686 2230 21



Ring

86223435

2686 2234 35



Shank bushing
D91115



Nut
C51153



Chuck
C51167



Diaphragm
D91145




Flow flange
C51122



Valve assembly
C51174



Pressure accumulator
C51146



Flushing housing
C53172



Ball bearing
4605220



Thrust washer-B
C53218



Socket bolt
4011151



Accumulator body
D91144



Seal ring kit
N78007



Front cylinder liner bush
N78104



Rear cylinder
N78105



Body swivel
N78114



Damping piston
N78110



Front cover
N78112



Seal retainer
N78108



Cylinder
N78100



Front bush
N78113



Front cylinder liner
N78103



Piston
N78101



Thrust washer
N78115



**Bearing
N78118**



**Bearing
N78125**



**Through hex nut
N78131**



**Bearing
N78121**



**Rotation coupling
N78126**



**Chuck
N78127**



**Gear housing
N78120**



**Hydraulic motor
N78138**



**Pinion gear
N78122**



**Rotation gear
N78120**



**Through bolt
N78130**



